

"Slim Light" SERIES FOR MAINTAINED / NON-MAINTAINED LUMINAIRES



TECHNICAL CHARACTERISTICS	GR-8/9led	GR-8/12led	GR-9/12led
OPERATION VOLTAGE	220-240V AC/50-60Hz		
MAXIMUM POWER CONSUMPTION	2.7W / 3VA		
BATTERIES (Ni-Cd)	3.6V/600mAh		3.6V/1Ah
INDICATIONS - CONTROLS	Battery charge indication LED, TEST button		
CHARGING TIME	24 h		
MINIMUM AUTONOMOUS DURATION	1.5 h		3 h
ILLUMINATION SOURCE	9 white LED's	12 white LED's	
ILLUMINATION (230V AC / emergency)	30lm / 65lm	40lm / 85lm	
DEGREES OF COVER PROTECTION	IP 20		
PRODUCED IN ACCORDANCE WITH	EN 60598-1, EN 60598-2-22, EN 55015, EN 61547, EN 61000-3-2, EN 61000-3-3		
OPERATION TEMPERATURE RANGE	0 to 40 °C		
RELATIVE HUMIDITY	Up to 95%		
CONSTRUCTION MATERIALS	Bayblend FR3010, transparent polycarbonate		
EXTERNAL DIMENSIONS	248 x 76 x 45 mm		
TYPICAL WEIGHT	345gr.		370gr.
GUARANTEE	3 years (1 year for the battery)		

Thank you for purchasing this product of Olympia Electronics. A European manufacturer.

GENERAL

These luminaires are used indoors (ta 40°C) where emergency light is needed.

Each luminaire must be permanently connected to mains power supply. In normal operation the illumination LEDs are lit as well as the green indicating charge Led when the battery is charging.

In case of a mains power supply failure the luminaire will light the led strip automatically in emergency mode. When the mains power supply is restored the device turns to normal operation.

Maintained / non-maintained operation there is an option to select the maintained or non-maintained operation by placing the jumper to the appropriate place according to the figure 3.

ATTENTION!!!

- Operations for installation, maintenance or testing must be done by authorized personnel only.
- The device must be connected to the mains power supply thru a fuse dependent by the total amount of the line's power load.
- It is suggested to check every month the indication LED for battery charging, and by pushing the TEST

button to check the emergency circuit. The led strip should light as long as the TEST button is pressed. If the luminaire doesn't work as described above contact the installer.

4. It is suggested to check every 6 months the minimum autonomous duration by disconnecting the mains power supply. Count the time that the led strip lights and in case of less time than the minimum autonomous duration the battery must be replaced. If the measured time is considerably less than the minimum autonomous duration contact the installer. In case of battery or led strip replacement, these must be replaced by parts of the same type, by the manufacturer or by a competent person.

5. In case of inactive use for a period greater than 2 months, disconnect the battery by pulling out the battery's connector.

6. It is not allowed to discard batteries in to common trash bins, they must be discarded only in battery recycling points. Do not incinerate.

INSTALLATION

To install the luminaire follow the installation instructions below.

Installation: 1. To instal the device you have to dismantle carefully the device with a flat screwdriver as shown in figure 1. 2. Pass the mains cables thru the hole (point 1 in figure 2). 3. Mount the base plastic on the wall by using the included mounting accessories in points 2 and 3 in figure 2. 4. Connect the battery's cable with the appropriate terminal (figure 3). 5. The connection with the mains cables will be done by using the terminal block as shown in figure 4. 6. Refit with care the removed plastic parts and power on the luminaire.



